

Network Camera

安全のために	Sicherheitsbestimmungen
Safety Regulations	Normative di sicurezza
Règlements de sécurité	安全規則
Normativa de seguridad	

お買い上げいただきありがとうございます。

警告
電気製品は、安全のための注意事項を守らないと、火災や人身事故になることがあります。

この「安全のために」には、事故を防ぐための重要な注意事項と製品の取り扱いかたを示しています。この「安全のために」と別冊の「設置説明書」をよくお読みの上、製品を安全に使ってください。お読みになったあとは、いつでも見られるところに必ず保管してください。

IPELA

お問い合わせは	
「 ソニー業務用商品相談窓口のご案内 」にある窓口へ	
ソニー株式会社	〒108-0075 東京都港区港南1-7-1
http://www.sony.co.jp/	


© 2012 Sony Corporation Printed in China
4441092020

安全のために

ソニー製品は安全に充分配慮して設計されています。しかし、電気製品は、まちがった使いかたをすると、火災や感電などにより死亡や大けがなど人身事故につながることもあります。事故を防ぐために次のことを必ずお守りください。

- 安全のための注意事項を守る。**

- 故障したり破損したり使わずに、ソニーの相談窓口に相談する。**

警告表示の意味 「安全のために」、「設置説明書」および製品では、次のような表示を行っています。表示の内容をよくご理解してから本文をお読みください。 警告 この表示の注意事項を守らないと、火災や感電などにより死亡や大けがなど人身事故につながる場合があります。 注意 この表示の注意事項を守らないと、感電やその他の事故によりけがをしたり周辺の物品に損害を与えたりすることがあります。	注意を促す記号  火災  感電 行為を禁止する記号  禁止  分解禁止  ぬれ手禁止  水ぬれ禁止 行為を指示する記号  指示
---	---

警告  火災  感電	下記の注意を守らないと、火災や感電、落下により死亡や大けがにつながる場合があります。
--	---

設置や配線工事のときに屋内配線や屋内配管を傷つけないよう気をつける

指示	特に壁に穴を開けたり、電源コードやケーブルを固定したりするときは充分に気を付けてください。屋内配線や屋内配管の傷は、火災や感電、漏電の原因となります。
------------------	--

指示	指定された電源コードや接続ケーブルを使う 設置説明書に記されている電源コードや、接続ケーブルを使わないと、火災や故障の原因となることがあります。
------------------	---

指示	水にぬれる場所で使用しない(室内型モデル) 水ぬれすると、漏電による感電、発火の原因となることがあります。
------------------	--

水ぬれ禁止	指定された電源電圧で使用する 指定されたものと異なる電源電圧で使用すると、火災や感電の原因となります。
---------------------	--

指示	設置は専門の工事業者に依頼する 設置にご依頼には、必ずお買い上げ店またはソニー業務用商品相談窓口にご相談ください。 壁や天井など高所への設置は、本機と取り付け金具を含む重量に充分耐えられる強度があることをお確かめの上、確実に取り付けてください。十分な強度がないと、落下して、大けがの原因となります。 落下事故防止のため、付属のワイヤーロープは必ず取り付けてください。 また、1年に一度は、取り付けがゆるんでいないことを点検してください。また、使用状況に応じて、点検の間隔を短くしてください。
------------------	---

指示	製品の設置は充分な強度のある場所に取り付ける 強度の不充分な場所に設置すると、落下、転倒などにより、けがの原因となります。
------------------	--

指示	機器や部品の取り付けは正しく行う 機器や部品の取り付け方、本機の分離・合体の方法を誤ると、本機や部品が落下して、けがの原因となることがあります。 設置説明書に記載されている方法に従って、確実に行ってください。
------------------	--

指示	雨のあたる場所や、油煙・湯気、湿気、ほこりの多い場所には設置しない(室内型モデル) 上記のような場所や設置説明書に記されている使用条件以外の環境に設置すると、火災や感電の原因となることがあります。
------------------	---

禁止	電源コードや接続ケーブルを傷つけない 電源コードや接続ケーブルを傷つくと、火災や感電の原因となります。 電源コードを加工したり、傷つけないように、電源コードに重いのを載せたり、引っ張ったりしない。 電源コードを抜くときは、必ずプラグを持って抜く。
------------------	--

禁止	不安定な場所に設置しない 次のような場所に設置すると倒れたり落ちたりして、故障やけがの原因になることがあります。 - ぐらついた台の上 - 傾いたところ - 振動や衝撃のかかるところ また、設置・取り付け場所の強度を充分にお確かめください。
------------------	--

指示	付属のワイヤーロープを利用して取りつける 高所での作業では機器の落下により通行人等に重大な危害を与えることがあります。
------------------	--

ねじ・ボルトはしっかりと締め付ける 取り付ける場所、材質によって適切な取り付けをしてください。
--

指示	可燃性ガスの発生する場所へは設置しない 本機は防爆機器ではありません。 本機の運転により爆発・火災の危険があります。
------------------	--

禁止	振動のある場所へは設置しない 軽度の振動があるときは、画像がブレる場合があります。
------------------	--

禁止	ひさしなどによる防雪(室外型モデル) - 積雪の重みにより、実際の重さが増す可能性があります。 - 積雪により本機周辺の通風が阻害される可能性があります。
------------------	--

指示	油煙・湯気、多い場所には設置しない(室外型モデル) 上記のような場所やこの設置説明書に記されている使用条件以外の環境に設置すると、火災や感電の原因となることがあります。
------------------	---

禁止	高所等の強風が予想される場所に設置しない(室外型モデル) - 高所では地上に比べてより強い風が吹きます。 - ビル風等、場所によっては地上でも強風の吹くところがあります。
------------------	--

禁止	塩害や腐食性ガスが発生する場所へは設置しない 金属の腐食により破壊、落下の原因になります。
------------------	--

禁止	電源コードやケーブルを窓やドアにはさみ込まない コードやケーブルが傷つくと、ショートによる火災や感電の原因となります。
------------------	--

指示	分解や改造をしない 分解や改造をすると、火災や感電、けがの原因となることがあります。 内部の点検や修理は、お買い上げ店またはソニー業務用商品相談窓口にご相談ください。
------------------	---

指示	熱器具に近づけたり、加熱しない 変形したり、故障したりするだけでなく、レンズの特性により火災、火傷の原因となることがあります。特に、意図に置くときなどはご注意ください。
------------------	---

ぬれ手禁止	ぬれた手で電源プラグをさわらない ぬれた手で電源プラグを抜き差しすると、感電の原因となることがあります。
---------------------	---

ぬれ手禁止	内部に水や異物を入れない 水や異物が入ると、火災の原因となります。 万一、水や異物が入ったときは、すぐに本機が接続されている電源供給機種の電源コードや本機の接続ケーブルを抜いて、お買い上げ店またはソニー業務用商品相談窓口にご相談ください。
---------------------	---

指示	指定した給電装置を使用する PoEの電源供給は、設置説明書で指定された給電装置を使用してください。 指定の装置を使用しないと、火災や感電、けがなどの原因となることがあります。
------------------	---

指示	接続の線は電源を切る 電源を入れたまま電源コードや接続ケーブルを接続すると、感電や故障の原因になることがあります。
------------------	--

指示	移動させるときは電源コード、接続ケーブルを抜く 接続したまま移動させると、コードが傷つくと、火災や感電の原因となることがあります。
------------------	--

指示	指定されたマウントアームを使用する(屋外型モデル) 指定以外のマウントアームを使用すると、機器内部への浸水や故障の原因となります。必ず指定のマウントアームを使用してください。
------------------	--

警告	重要 機器の名称と電気定格は、定格ラベルに表示されています。
------------------	---

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。	VCCI-A
--	---------------

使用上のご注意	ご使用の前に - 開梱してから、結露がある場合には結露がなくなってから電源を入れてください。 - 設置作業の前やカメラに触れるときは、静電除去を行ってください。 データ・セキュリティについて - ネットワークカメラを使用することにより、インターネットを通じて容易にカメラ映像にアクセスすることができます。一方で第三者によりネットワークを通じてモニタリング画像および音声を観覧、使用等される可能性があります。ネットワークカメラの設置およびご利用については、密写等のプライバシー、肖像権などを考慮のうえ、お客様の責任で行ってください。 - ネットワークカメラへのアクセス権限は、ユーザー名およびパスワードを設定することにより行われます。それ以上のカメラによる監視作業は行われません。 - 諸事情による本ネットワークカメラに関連するサービスの停止、中断については、ソニーは一切の責任を負いません。 - 必ず事前に記録テストを行い、正常に記録されていることを確認してください。本機や記録メディア、外部のストレージなどを使用中、万一これらの不具合により記録されなかった場合の記録内容の補償については、ご容赦ください。 - 諸事情による本ネットワークカメラに関連するサービスの停止、中断については、ソニーは一切の責任を負いません。 - 必ず事前に記録テストを行い、正常に記録されていることを確認してください。本機や記録メディア、外部のストレージなどを使用中、万一これらの不具合により記録されなかった場合の記録内容の補償については、ご容赦ください。
-----------------------	---

使用・保管場所について 次のような場所での使用および保管は避けてください。 - 極端に暑い所や寒い所（使用温度は別冊の「設置説明書」をご覧ください。） - 直射日光が長時間あたる場所や暖房器具の近く（室内型モデル） - 強い磁気を見えるもの近く - 強力な電波を発するテレビやラジオの送信所の近く - 強い振動や衝撃のある所 - 湯煙、湿気、多い場所 - 雨のあたるところ（室内型モデル） - 蛍光灯や窓の反射の影響を受けるところ - 不安定な照明の下（フリッカーを起こします。） - 放射線やX線が発生する場所 - エアコンの室外機付近など、温度変化が激しい場所（ドームカバーが曇ることがあります。） - 高所等の強風が吹く場所（室外型モデル） - 湯煙や腐食性ガス、可燃性ガスが発生する場所
--

放熱について 動作中は布などで包まないでください。内部の温度が上がり、故障や事故の原因になります。	放熱について 動作中は布などで包まないでください。内部の温度が上がり、故障や事故の原因になります。
--	--

輸送について - 持ち運ぶときは、必ず電源を切ってから運んでください。 - 輸送するときには、付属のカートンとクッション、または同等品で梱包し、強い衝撃を与えないようにしてください。	輸送について - 持ち運ぶときは、必ず電源を切ってから運んでください。 - 輸送するときには、付属のカートンとクッション、または同等品で梱包し、強い衝撃を与えないようにしてください。
--	--

取り付け方について(室内型モデル) この製品は、ドームカバーが垂直下向きに、傾かないよう吊り下げて設置してください。	取り付け方について(室内型モデル) この製品は、ドームカバーが垂直下向きに、傾かないよう吊り下げて設置してください。
---	---

設置時の温度について(室外型モデル) 本機の設置は、湿度の高いときに行ってください。湿度の高いときに設置を行うと、動作中にドームカバー内に付着した雪や霜を解凍できません。	設置時の温度について(室外型モデル) 本機の設置は、湿度の高いときに行ってください。湿度の高いときに設置を行うと、動作中にドームカバー内に付着した雪や霜を解凍できません。
--	--

寒冷地での使用について(ヒーター付きモデル) 本機内部にはヒーターが内蔵され、内部温度が低下すると自動的に動作します。また、環境によっては、ドームカバー内に付着した雪や霜を解凍できません。	寒冷地での使用について(ヒーター付きモデル) 本機内部にはヒーターが内蔵され、内部温度が低下すると自動的に動作します。また、環境によっては、ドームカバー内に付着した雪や霜を解凍できません。
---	---

低温環境での起動・終了について(ヒーター付きモデル) 0℃未満の環境で起動すると、起動直後はカメラ本体システムが動作しないことがあります。その場合、ヒーターが動作して内部温度が上昇後にカメラ本体が起動します。正常な画像が得られるまでに2時間程度かかる場合があります。HiPoE+での電源供給時は、0℃未満では起動できません。 0℃以下の環境で電源を切ると、ドームカバー内が曇ることがあります。電源を再投入しても曇りがすぐに消えない場合があるため、短時間の休止後に再度使用する場合は、電源を切らないことをお守りめします。	低温環境での起動・終了について(ヒーター付きモデル) 0℃未満の環境で起動すると、起動直後はカメラ本体システムが動作しないことがあります。その場合、ヒーターが動作して内部温度が上昇後にカメラ本体が起動します。正常な画像が得られるまでに2時間程度かかる場合があります。HiPoE+での電源供給時は、0℃未満では起動できません。 0℃以下の環境で電源を切ると、ドームカバー内が曇ることがあります。電源を再投入しても曇りがすぐに消えない場合があるため、短時間の休止後に再度使用する場合は、電源を切らないことをお守りめします。
---	---

SDカードに関して SDカードに記録したデータは、以下の場合に破損したり、消失したりする可能性があります。データの破損や消失による損害や賠償、逸失利益については、弊社は一切の責任を負いかねますので、ご了承ください。 - SDカードにアクセス中に、本機から取り出したり、本機電源を切ったりした場合 - SDカードに衝撃が加った場合 - SDカードが製品寿命になった場合（使用方法により、製品寿命は大幅に短くなる場合があります。） - SDカードが正しく装着されなかった場合	SDカードに関して SDカードに記録したデータは、以下の場合に破損したり、消失したりする可能性があります。データの破損や消失による損害や賠償、逸失利益については、弊社は一切の責任を負いかねますので、ご了承ください。 - SDカードにアクセス中に、本機から取り出したり、本機電源を切ったりした場合 - SDカードに衝撃が加った場合 - SDカードが製品寿命になった場合（使用方法により、製品寿命は大幅に短くなる場合があります。） - SDカードが正しく装着されなかった場合
---	---

お手入れについて - レンズや光学フィルターの表面に付着したごみやほこりは、プロアで払ってください。 - 外装の汚れは、乾いたやわらかい布で軽く拭き取ってください。汚れがひどいときは、中性洗剤溶液を少し含ませた布で汚れを拭き取ったあと、からがししてください。 - アルコール、ベンジン、シンナー、殺虫剤など揮発性のものをかけると、表面の仕上げをいためたり、表示が消えたりすることもあります。 異常や不具合が起きたときは、お買い上げ店またはソニー業務用商品相談窓口にお問い合わせください。	お手入れについて - レンズや光学フィルターの表面に付着したごみやほこりは、プロアで払ってください。 - 外装の汚れは、乾いたやわらかい布で軽く拭き取ってください。汚れがひどいときは、中性洗剤溶液を少し含ませた布で汚れを拭き取ったあと、からがししてください。 - アルコール、ベンジン、シンナー、殺虫剤など揮発性のものをかけると、表面の仕上げをいためたり、表示が消えたりすることもあります。 異常や不具合が起きたときは、お買い上げ店またはソニー業務用商品相談窓口にお問い合わせください。
--	--

レーザービームについてのご注意 レーザービームは画像素子に損害を与えることがあります。レーザービームを使用した撮影環境では、画像素子表面にレーザービームが照射されないよう十分注意してください。	レーザービームについてのご注意 レーザービームは画像素子に損害を与えることがあります。レーザービームを使用した撮影環境では、画像素子表面にレーザービームが照射されないよう十分注意してください。
---	---

撮像素子特有の現象	撮像素子特有の現象 撮影画面に出る下記の現象は、撮像素子特有の現象で、故障ではありません。 白点 撮像素子は非常に精密な技術で作られていますので、宇宙線などの影響により、まれに画面上に微小な白点が発生する場合があります。これは撮像素子の内部に起因するもので故障ではありません。 また、下記の場合、白点が見えやすくなります。 - 高温の環境で使用するとき - ゲイン(感度)を上げたとき - スローシャッターのとき
-------------------------	---

折り返ししずみ 細い模様、線などを撮影すると、ギザギザやちがうが見えることがあります。	折り返ししずみ 細い模様、線などを撮影すると、ギザギザやちがうが見えることがあります。
--	--

保証書とアフターサービス	保証書 この製品には保証書が添付されていますので、お買い上げの際にお受け取りください。 所定事項の記入および記載内容をお確かめのうえ、大切に保存してください。 アフターサービス 調子が悪いときはまずチェックをこの「安全のために」と別冊の「設置説明書」をもう一度ご覧になってお調べください。 それでも具合が悪いときはサービスへ お買い上げ店、またはお近くのソニー業務用商品相談窓口にご相談ください。 保証期間中の修理は 保証書の記載内容に基づいて修理させていただきます。詳しくは保証書をご覧ください。 保証期間経過後の修理は 修理によって機能が維持できる場合は、ご希望により有料修理させていただきます。
----------------------------	---

定期点検のお願い 本機を長期間ご使用になる場合は、安全にお使いいただくため、定期点検をお願いします。 外観上は異常がなくても、使用頻度によって部品が劣化している可能性があります。故障したり事故につながる場合があります。 ◆詳しくはお買い上げ店またはソニーの相談窓口にご相談ください。	定期点検のお願い 本機を長期間ご使用になる場合は、安全にお使いいただくため、定期点検をお願いします。 外観上は異常がなくても、使用頻度によって部品が劣化している可能性があります。故障したり事故につながる場合があります。 ◆詳しくはお買い上げ店またはソニーの相談窓口にご相談ください。
--	--

補修用部品の保有年数 補修用性能部品は製造打ち切り後、7年間保有します。	補修用部品の保有年数 補修用性能部品は製造打ち切り後、7年間保有します。
---	---

English	English
-----------------------	-----------------------

WARNING To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. (Except outdoor models) To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.	WARNING To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. (Except outdoor models) To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.
--	--

Operating or storage location Avoid operating or storing the camera in the following locations. - Extremely hot or cold places (for operating temperature, see Installation Manual). - Exposed to direct sunlight for a long time, or close to heating equipment (e.g., near heaters) (Indoor models) - Close to sources of strong magnetism - Close to sources of powerful electromagnetic radiation, such as radios or TV transmitters - Locations subject to strong vibration or shock - Locations subject to steam or high humidity - Locations exposed to rain (Indoor models) - Locations under the influence of fluorescent light or reflection of a window - Under an unsteady light (the image will flicker) - Locations where radiation or X-rays are emitted - Near the outdoor unit of an air conditioner or any other place where drastic temperature changes may occur (this may cause clouding of the dome cover) - Locations subject to strong wind, such as high places (Outdoor models) - Locations where corrosive gas or flammable gas is emitted, or where salt damage may occur	Operating or storage location Avoid operating or storing the camera in the following locations. - Extremely hot or cold places (for operating temperature, see Installation Manual). - Exposed to direct sunlight for a long time, or close to heating equipment (e.g., near heaters) (Indoor models) - Close to sources of strong magnetism - Close to sources of powerful electromagnetic radiation, such as radios or TV transmitters - Locations subject to strong vibration or shock - Locations subject to steam or high humidity - Locations exposed to rain (Indoor models) - Locations under the influence of fluorescent light or reflection of a window - Under an unsteady light (the image will flicker) - Locations where radiation or X-rays are emitted - Near the outdoor unit of an air conditioner or any other place where drastic temperature changes may occur (this may cause clouding of the dome cover) - Locations subject to strong wind, such as high places (Outdoor models) - Locations where corrosive gas or flammable gas is emitted, or where salt damage may occur
--	--

Ventilation To prevent heat buildup, do not block air circulation around the camera.	Ventilation To prevent heat buildup, do not block air circulation around the camera.
---	---

Transportation - Always turn off the power when carrying. - When transporting the camera, repack it as originally packed at the factory or in materials of equal quality.	Transportation - Always turn off the power when carrying. - When transporting the camera, repack it as originally packed at the factory or in materials of equal quality.
--	--

Installation (Outdoor models) Ensure that the dome cover is installed facing perpendicularly downward without any tilt.	Installation (Outdoor models) Ensure that the dome cover is installed facing perpendicularly downward without any tilt.
--	--

Humidity when installing the device (Outdoor models) Install this device under low humidity condition. Otherwise the dome cover may cloud up during operation.	Humidity when installing the device (Outdoor models) Install this device under low humidity condition. Otherwise the dome cover may cloud up during operation.
---	---

Using in cold climates (Models with integrated heater) This device is equipped with a built-in heater, which automatically turns on if the internal temperature is significantly low. Note that, in some environments, the heater may not melt snow or frost on the dome cover.	Using in cold climates (Models with integrated heater) This device is equipped with a built-in heater, which automatically turns on if the internal temperature is significantly low. Note that, in some environments, the heater may not melt snow or frost on the dome cover.
--	--

Starting and closing under low temperature (Models with integrated heater) - In temperatures below 0 °C (32 °F), the camera system may not start up immediately. In such a case, the heater activates to raise the internal temperature, and then the camera system starts. It may take about two hours for the camera system to start streaming normal images. If the power is supplied by HiPoE+, the camera cannot be started in temperatures below 0 °C (32 °F). - If the unit is turned off in an ambient temperature of 0 °C (32 °F) or below, condensation may occur in the dome cover, which may take some time to clear after turning the unit on again. In order to prevent the prolonged condensation, it is recommended that to leave this unit powered on for a short term recess, in that environment.	Starting and closing under low temperature (Models with integrated heater) - In temperatures below 0 °C (32 °F), the camera system may not start up immediately. In such a case, the heater activates to raise the internal temperature, and then the camera system starts. It may take about two hours for the camera system to start streaming normal images. If the power is supplied by HiPoE+, the camera cannot be started in temperatures below 0 °C (32 °F). - If the unit is turned off in an ambient temperature of 0 °C (32 °F) or below, condensation may occur in the dome cover, which may take some time to clear after turning the unit on again. In order to prevent the prolonged condensation, it is recommended that to leave this unit powered on for a short term recess, in that environment.
---	---

About the SD Memory Card Data on the SD Memory Card may be damaged or deleted in the following cases. Sony is not responsible for compensation for damage or lost earnings due to damage or loss of data. - If you remove the SD Memory Card from this device or turn off the power while the SD Memory Card is being accessed. - If the SD Memory Card is subject to shock. - When the lifetime of the SD Memory Card expires. (Lifetime may shorten significantly, depending on its use.) - If the SD Memory Card is not set or inserted properly.	About the SD Memory Card Data on the SD Memory Card may be damaged or deleted in the following cases. Sony is not responsible for compensation for damage or lost earnings due to damage or loss of data. - If you remove the SD Memory Card from this device or turn off the power while the SD Memory Card is being accessed. - If the SD Memory Card is subject to shock. - When the lifetime of the SD Memory Card expires. (Lifetime may shorten significantly, depending on its use.) - If the SD Memory Card is not set or inserted properly.
--	--

Caution for LAN port Use a power supply which meets the requirements for SELV (Safety Extra Low Voltage) and complies with Limited Power Source according to IEC 60950-1 Second Edition.	Caution for LAN port Use a power supply which meets the requirements for SELV (Safety Extra Low Voltage) and complies with Limited Power Source according to IEC 60950-1 Second Edition.
---	---

CAUTION for LAN port For safety reason, do not connect the LAN port to any network devices that might have excessive voltage. The LAN port of this unit is to be connected only to the devices whose power feeding meets the requirements for SELV (Safety Extra Low Voltage) and complies with Limited Power Source according to IEC 60950-1. Use IEEE802.3af standard compliant devices.	CAUTION for LAN port For safety reason, do not connect the LAN port to any network devices that might have excessive voltage. The LAN port of this unit is to be connected only to the devices whose power feeding meets the requirements for SELV (Safety Extra Low Voltage) and complies with Limited Power Source according to IEC 60950-1. Use IEEE802.3af standard compliant devices.
--	--

IMPORTANT The product name and electric rating are located on the Rating Label.	IMPORTANT The product name and electric rating are located on the Rating Label.
--	--

For customers in the U.S.A.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
--	--

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.	This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.</
--	---

Español

ADVERTENCIA

Para reducir el riesgo de electrocución, no exponga este aparato a la lluvia ni a la humedad (Excepto modelos para exterior)